

March 16, 2022

Pipeline Set-in (Above Ground Construction)

PURPOSE/APPLICATION

To provide guidance on the process for setting in an above ground pipeline. The process for the welding of the pipeline is specifically covered in SJP-31 Pipeline Welding.

PPE
Hearing Protection
Strike Minimum PPE
Welding Helmet
Face Shield

TRAINING • Minimum Strike and Site Requirements

Equipment Operator Competency

TOOLS/EQUIPMENT • Mechanical • Grinders

Welding Equipment
 Propane Tanks and Torches

Slings

#	Job Steps	Hazards	Control Measures		
1	Buff pipe ends	 Flying Debris/Sparks Pinch/Crush Points Rotational hazards Awkward body positioning 	 Ensure double eye protection is being utilized while grinding, buffing, chipping, etc. Ensure all required PPE is being utilized. Stay out of the line of fire. Ensure combustible materials are managed on ROW and have adequately placed fire extinguisher present. 		
2	Pre-heat pipe with tiger torch to specified temperature	 Fire and Explosion Burns/Hot surfaces Trip hazard from hose Compressed gas cylinder 	 Fire extinguisher present. Ensure appropriate hand protection is being worn. Ensure hot work permit is in place, as required. Ensure heating torch gas tanks and hoses are out of the line of fire to not create a trip hazard. 		
3	Lift clamp into place, halfway over the end of the pipe to accept the next pipe and hand tighten (for larger clamps or at high elevation utilize side boom and sling)	 Pinch/Crush points Mechanical failure Rigging failure Dropped objects Falls from height 	 Utilize pipe clamp handles to place clamps at the edge of the pipe and hand tighten to secure and eliminate from movement. Wear task appropriate gloves to prevent cuts, pinches, and abrasions while placing clamps. Complete a pre-use inspection on all rigging and lifting devices; remove all damaged 		



March 16, 2022 Pipeline Set-in (Above Ground Construction)					
		-	equipment from service.		
			 Ensure all access equipment is inspected and level prior to accessing elevated work. 		
			 Keep non-essential workers clear of immediate work area and ensure no workers are below when setting clamps. 		
			 Never walk under a suspended load. 		
4	Fit sling onto pipe, lift pipe with Side Boom/Picker truck/Mobile crane and insert pipe end into clamps	Pinch/Crush pointsMechanical failureCrush potential	 Pre inspect all equipment and rigging prior to use and take any damaged equipment out of service. 		
		Suspended loadsRigging failure	 Never work under a suspended load. 		
		 Struck by/Against an object 	 Never drag the sling down the pipe section with the side boom, always unhook the sling to move to the next lifting section. 		
			 Ground worker to pass tagline to stabber when working at an elevated position in order to maintain control of pipe. 		
			 Control pipe motion into the clamps by manipulating pipe on the down-work side (opposite of the clamp) by pushing/pulling on the body of the pipe (not the pipe ends). 		
			 Spacer to signal when all worker's hands are clear of the working end of the pipe prior to signaling equipment to bring pipe end into clamps. 		
			 Stabber to visually verify pipe is free of debris prior to inserting pipe into clamps. 		
			 Never stand between pipe in motion and sleeper/pile or any other crush point. 		
4	Tack pipe together at joint ends	 ❖ Welding flash ❖ Flying debris 	 Ensure welding helmets are being utilized. 		
		Flying debrisSparks	 Use double eye protection. 		



Ma	arch 16, 2022	Pipeline Set-in (Above Ground Construction)			
		❖ Stored energy	 Ensure sufficient tack welds are in place before releasing clamps (pipe cover at least 50% before removing clamps). 		
5	supports or skid column to protect weld tack integrity	Uneven ground conditions	 Ensure pipe cones or skids are sitting on level ground. 		
		 Pinch/Crush points 	 Stay out of the line of fire. 		
		 Damaged skids or cones 	 Ensure cones or skids are in good condition and replace all damaged ones. 		
		 Miscommunication 	 Ensure cones and/or skids are of adequate size and rated for the pipe weight. 		
			 Use a spotter when necessary to give signals to operator. 		
			 If on skids, make sure the pipe is chocked and cannot roll off. 		
			 If setting pipe on above ground racks, ensure pipe is placed in shoes or secured with wedges or straps to limit potential to shift/roll. 		

ADDITIONAL PRECAUTIONS:

- When utilizing handles to positioning clamps be aware of latch pinch points.
- Lift in trams or use mechanical lifting devices to move clamps, as required.
- Utilize equipment when lowering clamps from elevated positions.



March 16, 2022

Pipeline Set-in (Above Ground Construction)

REFERENCE/REGULATIONS

Alberta OH&S Code

- Part 10 Fire and Explosion Hazards
- Part 18 Personal Protective Equipment
- Part 14 Lifting and Handling Loads
- Part 18 Personal Protective Equipment
- Part 19 Powered mobile equipment
- Part 21 Rigging

British Columbia OH&S Regulation

- Part 4 General Conditions Section 4.13
- Part 4 Emergency Preparedness and Response
- Part 8 Personal Protective Clothing and Equipment
- Part 14 Cranes and hoists
- Part 15 Rigging
- Part 16 Mobile Equipment

Saskatchewan OH&S Regulations

- Part 7 Personal Protective Equipment
- Part 13 Hoists, Cranes and Lifting Devices
- Part 22 Controlled Products
- Part 25 Fire and Explosion Hazards

Manitoba OHS Regulations

- Part 6 Personal Protective Equipment
- Part 22 Powered Mobile Equipment
- Part 23 Cranes and Hoists

Developed by:	1.	Kevin Wark	2.	Thomas Mackay	Date:	Feb 19, 2022
	3.	Kirk Long	4.	Robbie Briand		
	5.	Cord Roberts	6.	Allen Monk	_	
Approved by:	1.	HSE Committee	_		_ Date:	March 16, 2022